

How to change the date on your Aspire phone system

From any display phone, with the handset in the cradle:

Press CALL1

Dial #*#*

Dial 12345678

Dial HOLD

Dial 10-01-01

Following the prompts

Dial Year + HOLD

Dial month +HOLD

Dial day + HOLD

Dial week + HOLD

Dial hour + HOLD

Dial minute + HOLD

Dial second + HOLD

Hit the MSG key twice

Hit the Dial key